

FENDER FLARE INSTALLATION INSTRUCTION

SILVERADO/GMC SIERRA 99-06 • SILVERADO/GMC SIERRA 01-06 • SILVERADO CLASSIC 07

Parts

Qty (1) Fender Flare Left Front (LF)
Qty (1) Fender Flare Left Rear (LR)
Qty (1) Fender Flare Right Front (RF)
Qty (1) Fender Flare Right Rear (RR)

Qty (1) Rubber Seal (enough for four flares's outer edge)
Qty (24) Plastic Expanding Fastener
Qty (8) Self Tapping Screw (see **option B**)

Pre-Installation

RF (Right Front)




LR (Left Rear)
DRIVER SIDE

LF (Left Front)

Pre-fit and ensure both driver side and passenger side fender flares to the vehicle before painting or installation. You may remove any moldings, strips or existing flares from the vehicle for fitting or installation. You can cut the fender flare to fit any body side molding.

Painting (optional A)



Professional painter or body shop recommended to paint flares. Follow all the paint manufacture specifications to paint the flares. Clean fender flare surfaces with clean water and a mild detergent before painting, do not use lacquer thinner or any solvent based products.

Cleaning




Wash and wipe dry the areas of contact on the vehicle body. Clean the surface and inside edge of the fender flare where the rubber seal is to be attached.

Apply Rubber Seal




Remove about 1 inch tape liner from rubber seal and apply it on the flare. Start one end of the flare along the edge that comes in contact with the body panel. Apply pressure on the tape to ensure adhesion, and trim excess rubber seal at the end.

Installation (Left Front Flare Shown)



Place the flare on the vehicle. Apply 5 Plastic Expanding Fastener into the mounting slots in flare and secure it to the vehicle as shown.

Installation (Left Rear Flare Shown)



Place the flare on the vehicle. Apply 7 Plastic Expanding Fastener into the mounting slots in flare and secure it to the vehicle as shown.

option B: If condition of fender prevents use of Expanding Fastener you can use the included self tapping screws to secure the flare to the fender.