

## FENDER FLARE INSTALLATION INSTRUCTION FORD F-150 09-up

### Parts

Qty (1) Fender Flare Left Front (LF)  
Qty (1) Left Front Inner Piece (LF-L)  
Qty (1) Fender Flare Left Rear (LR)  
Qty (1) Fender Flare Right Front (RF)  
Qty (1) Right Front Inner Piece (RF-R)  
Qty (1) Fender Flare Right Rear (RR)


Qty (1) Rubber Seal (enough for four flares's outer edge)  
Qty (2) U-Clips & Flange Type-D Screws  
Qty (8) Long Clips & Truss Type-A Screws  
Qty (8) Plastic Fasteners  
Qty (8) Self Tapping Screws (see **option B**)

### Step 1. Pre-Installation




Pre-fit both driver side and passenger side fender flares to the vehicle before painting or installation. You may remove any moldings, strips or existing flares from the vehicle for fitting or installation. You can cut the fender flare to fit any body side molding.

### Step 2. Painting (optional)




Professional paint or body shop recommended to paint flares. Follow all the paint manufacture specifications to paint the flares. Clean fender flare surfaces with clean water and a mild detergent before painting, do not use lacquer thinner or any solvent based products.

### Step 3. Cleaning




Wash and wipe dry the areas of contact on the vehicle body. Clean the surface and inside edge of the fender flare where the rubber seal is to be attached.

### Step 4. Apply Rubber Seal




Remove about 1 inch of tape liner from rubber seal and apply it to the flare. Start at one end of the flare along the edge that comes in contact with the body panel. Apply pressure on the tape to ensure adhesion, and trim excess rubber seal at the end.

### Step 5. Installation (Left Front Flare Shown)



Remove the three existing factory screws with proper wrench and save it for reinstallation, as shown.



Install a U-Clip over existing factory hole on the fender well lip, as top shown. Fasten the 2 existing factory screws through inner piece & into the original location, as bottom shown. Apply one Flange Type-D screws through inner piece & U-Clip to the vehicle on the uppermost hole, as center shown.

**Option B:** If condition of fender prevents use of the Push-In Clips you can use the included self tapping screws to secure the flare to the fender.

**855-787-8334**


[www.trueedgeproducts.com](http://www.trueedgeproducts.com)

**Step 5. (Continued)**



**F3**

Fasten the 1 existing factory screw into the original location what was previously removed, as shown.



**F4**

Drill through bumper cover with a 1/4" drill bit from the forward most hole in the flare, as shown. Secure the flare with four Plastic Fasteners to the vehicle, include the hole drilled on the bumper cover, as right shown.

**Step 6. Installation (Left Rear Flare Shown)**




**R1**

Remove the two existing factory screws with proper wrench and save it for reinstallation as shown.




**R2**

Place the flare on the vehicle, mark the four holes location into the vehicle, as shown.



**R3**

Apply four long clips over the marks that were made in Step R2 as shown.



**R4**

Secure the flare with four Truss Type-A screws to the vehicle, start the two screws on the two topmost holes first, line up and secure other two screws, as top shown. Fasten the 2 existing factory screws into the original location that were previously removed, as bottom shown.

**Option B:** If condition of fender prevents use of the Push-In Clips you can use the included self tapping screws to secure the flare to the fender.

**855-787-8334**

[www.trueedgeproducts.com](http://www.trueedgeproducts.com)